



## GENERIC S.L.A.T. LAYOUT AND INSTALL CLOSURE FOR INTERMITTENT MOVING WORK ZONE

Project: Moving Work Zone S.L.A.T CL Layout

Comments:

1) Install delineators just off centre of CL so the side you are doing measurements from is bigger

2) When work in closure complete and starting to move, walk to new closure off of the road

3) TCP stops traffic from the side of the travel lane and moves in front of vehicles once they are stopped









